

## UV-Cured Primer Surfer

# SU1280

SU1280, UV-Cured Primer Surfer is designed to quickly and professionally repair small to medium repairs with the ease and efficiency of UV processing that can be over coated with many of PPG refinsh topcoats or systems.

SU1280, UV-Cured Primer Surfer is easy to spray and uses technology that allows you to sand the primer surfer just two minutes after application.

Additionally as part of our *OneChoice* UV Primer Collection we are proud to offer the following:

- DEXUVL UV LED Light
- SAS5346 UV Protective Glasses
- SAS66518 (L) 6 mil UV Protective Gloves
- SAS66519 (XL) 6 mil UV Protective Gloves
- DEX500 Timer with magnet

All items are available individually.



### Features & Benefits

- Ideal for rapid repair process
- High Build
- 2-minute cure
- Ready-to-use
- Maximum productivity
- Labor savings
- Increased vehicle throughput
- Minimal flash between coats.

### Compatible Surfaces

- Properly cleaned and sanded steel, aluminum, fiberglass and galvanized steel.
- Cured and sanded OEM finishes (except lacquer or 1K finishes)
- Cured and sanded refinsh topcoat systems.
- Polyester Body Fillers
- All properly prepared rigid and semi-rigid plastic except PE and Polystyrene

### Compatible Products

- ENVIROBASE® High Performance Waterborne Basecoat Systems
- AQUABASE® Plus Waterborne Basecoat Systems
- DELTRON® 2000 (DBC) Basecoat Systems
- NEXA AUTOCOLOR® 2K P420/P421/P422 Color Systems
- GLOBAL REFINISH SYSTEM™ (BC) Basecoat Color Systems
- *Deltron* Undercoats
- *Envirobase* High Performance Undercoats
- *Aquabase* Plus Undercoats
- *Nexa Autocolor* 2K Undercoats
- *Global Refinish System* Undercoats

## Directions for Use:

### Surface Preparation:



- Wash all surfaces to be painted with soap and water, then apply the appropriate substrate cleaner. Ensure that the substrate is thoroughly cleaned and dried both before and after application work.
- Finish sanded bare metal areas with 180 grit abrasive. Do not apply etch primer before UV priming.
- Sand old finishes with 320-400 grit dry by hand or machine or 600 grit wet.
- Wash off residue and dry thoroughly before re-cleaning with an appropriate systems substrate cleaner. The use of a tack rag is recommended.
- Prime aluminum and stainless substrate within 8 hours.
- Prime carbon steel immediately after sanding and cleaning.
- Adhesion promoter must be applied to bare plastic before priming with SU1280. See *OneChoice* bulletin OC-35 for additional information.



### Mixing:



SU1280 is ready to spray.

**Note:** Mechanically agitate. Do not utilize a mixing lid or place on a mixing bank. Utilizing a black/opaque pvc spray cup will lengthens the life of the UV paint in the cup.

### Application Procedure:



Apply: 2 wet coats  
Dry film Build: 2.0 - 2.5 mil per coat

**Note:** UV Primer is transparent with some effect pigmentation to visually assist with application. DO NOT attempt to spray to hiding and DO NOT exceed more than 2 coats of UV primer. Do not apply in direct sunlight. Excessive film builds will require additional UV light exposure.

### Air Pressure and Gun Setup:



HVLP: 10 psi at the air cap  
Compliant: 29 - 40 psi at the gun

Fluid Tip: 1.0 - 1.2 mm or equivalent

**Note:** For best results, we recommend a mini-gun with a 1.0 -1.2 fluid tip. For best overall results, refer to spray gun manufacturer's recommendations for UV tip size and inlet air pressures.

### Flash Time:



Between Coats: 30 seconds between coats, but NO flash before curing.

Use Personal Protective Equipment (PPE) to prevent UV radiation damage

- Part number SAS5346 UV Protective Safety Glasses
- Part number SAS66518 (L) or SAS66519 (XL) Nitrile 6 mil Gloves



Immediately after final coat:

Cure 2-3 minutes: Hold UV-A LED Light 6-8 inches away from panel. Continuously move over entire repair area when repair area is larger than 6 inches around.

### Cure Process:



UV Primer must be cured with DEXUVL UV LED Light or other UV Lamps with the same UVA wavelength (395 nm). UV curing only occurs with direct exposure, be sure to keep UV light source perpendicular to all panels surfaces for the required amount of time.

Always follow manufacturer's instructions and safety precautions for the proper use of UV emitting equipment.

Always protect your eyes from direct exposure to UV light radiation. The SAS5346 UV Protective Safety Glasses are needed to protect your eyes from reflective UV radiation. To avoid incidental UV radiation exposure to other people, always use UV emitting equipment behind shielded curtains.

UV primer can be cured by direct sunlight. Exposure time is directly dependent on UV intensity (average time is 10-30 mins.). Primer cannot be cured in the rain or inclement weather.

## Directions for Use Cont'd:

### Dry to Sand:



Immediately after curing. Repair is ready to sand.

### Performance Guidelines:



Wear full UV protection equipment to prevent UV radiation damage to yourself and use UV light emitting equipment behind shields to prevent exposure to others.

UV Primer is designed to be transparent. A transparent film allows UV light to easily penetrate the film and ensures a more thoroughly cured film. The effect pigmentation is only intended to visually assist during application.

UV Primer cannot be used on original or refinish thermoplastic coatings, specifically lacquer or 1K finishes.

Bare plastic requires an adhesion promoter prior to applying SU1280 UV primer. Ensure the repair area is thoroughly prepped and sanded per normal procedures.

Clean cured UV Primer surface before sanding to minimize sandpaper usage.

The contents of this package may have to be blended with other components before the product can be used. Before opening the packages, be sure you understand the warning messages on the labels and SDS/MSDS's of all the components, since the mixture will have the hazards of all of its parts.

### Health and Safety:



Improper handling and use, for example, poor spray technique, inadequate engineering controls and/or lack of proper Personal Protective Equipment (PPE), may result in hazardous conditions or injury.

Follow spray equipment manufacturer's instructions to prevent personal injury or fire.



Provide adequate ventilation for health and fire hazard control.

Follow company policy, product SDS/MSDS and respirator manufacturer's recommendations for selection and proper use of respiratory protection. Be sure employees are adequately trained on the safe use of respirators per company and regulatory requirements.



Wear appropriate PPE such as eye and skin protection. In the event of injury, see first aid procedures on SDS/MSDS.

Always observe all applicable precautions and follow good safety and hygiene practices.

### Equipment Cleaning:

Spray guns, gun cups, storage pots, etc. should be cleaned thoroughly after each use with any PPG general purpose solvent, lacquer thinner or DT reducer.

## Technical Data:

### RTU:

	SU1280
Volume Ratio	Ready-to-spray as packaged
Applicable Use Category	Primer Surfacers
VOC Actual (g/L)	1
VOC Actual (lbs./gal.)	0.01
VOC Regulatory (less water less exempt) (g/L)	1
VOC Regulatory (less water less exempt) (lbs./gal.)	0.01
Solids by weight	76.0
Solids by volume	64.2
Sq. Ft. Coverage / US Gal., 2.0 mil at 100% transfer efficiency	515

See Safety Data Sheet and Labels for additional safety information and handling instructions.

**Important:** The contents of this package must be blended with other components before the product can be used. Before opening the packages, be sure you understand the warning messages on the labels of all components since the mixture will have the hazards of all its parts. Improper spray technique may result in a hazardous condition. Follow spray equipment manufacturer's instructions to prevent personal injury or fire. Follow directions for respirator use. Wear eye and skin protection. Observe all applicable precautions.

**EMERGENCY MEDICAL OR SPILL CONTROL INFORMATION (412) 434-4515; IN CANADA (514) 645-1320**

Materials described are designed for application by professional, trained personnel using proper equipment and are not intended for sale to the public. Products mentioned may be hazardous and should only be used according to direction, while observing precautions and warning statements listed on label. Statements and methods described are based upon the best information and practices known to PPG Industries. Procedures for applications mentioned are suggestions only and are not to be construed as representations or warranties as to performance, results, or fitness for any intended use, nor does PPG Industries warrant freedom from patent infringement in the use of any formula or process set forth herein.

PPG  
Automotive Refinish  
19699 Progress Drive  
Strongsville, OH 44149  
800.647.6050

PPG Canada Inc.  
2301 Royal Windsor Drive, Unit #6  
Mississauga, Ontario L5J 1K5  
888.310.4762

Follow us online:  
[www.ppgrefinish.com](http://www.ppgrefinish.com)



The PPG Logo, Aquabase, Concept, Deltron, Envirobases, OneChoice, and We protect and beautify the world are registered trademarks, and Global Refinish System and Nexa Autocolor are trademarks of PPG Industries Ohio, Inc. © 2021 PPG Industries, Inc. All rights reserved.